

BPN-NVMe3-136NB-L Backplane
BPN-NVMe3-136NB-R Backplane
BPN-NVMe3-136PL Backplane
BPN-NVMe3-136PL-J Backplane
USER'S GUIDE

Rev. 1.0

The information in this User's Manual has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, makes no commitment to update or to keep current the information in this manual, or to notify any person or organization of the updates. **Please Note: For the most up-to-date version of this manual, please see our web site at www.supermicro.com.**

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software, if any, and documentation may not, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any medium or machine without prior written consent.

IN NO EVENT WILL SUPERMICRO BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPERMICRO SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Super Micro's total liability for all claims will not exceed the price paid for the hardware product.

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate"

WARNING: Handling of lead solder materials used in this product may expose you to lead, a chemical known to the State of California to cause birth defects and other reproductive harm.

Manual Revision 1.0
Release Date: January 2, 2017

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2017 by Super Micro Computer, Inc.
All rights reserved.

Printed in the United States of America

Table of Contents

Contacting Supermicro.....	iv
Returning Merchandise for Service.....	v
Chapter 1 Safety Guidelines	
1-1 ESD Safety Guidelines	1-1
1-2 General Safety Guidelines	1-1
1-3 An Important Note to Users	1-2
1-4 Introduction to the Backplanes	1-2
Chapter 2 Connectors and Pin Definitions	
2-1 Front Connectors	2-1
2-2 Front Connector Pin Definitions.....	2-3
2-3 Front Jumper Locations and Pin Definitions.....	2-5
2-4 Rear Connectors and LED Indicators	2-6

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000

Fax: +1 (408) 503-8008

Email: marketing@supermicro.com (General Information)
support@supermicro.com (Technical Support)

Web Site: www.supermicro.com

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390

Fax: +31 (0) 73-6416525

Email: sales@supermicro.nl (General Information)
support@supermicro.nl (Technical Support)
rma@supermicro.nl (Customer Support)

Asia-Pacific

Address: Super Micro Computer, Inc.
4F, No. 232-1, Liancheng Rd.
Chung-Ho 235, Taipei County
Taiwan, R.O.C.

Tel: +886-(2) 8226-3990

Fax: +886-(2) 8226-3991

Web Site: www.supermicro.com.tw

Technical Support:

Email: support@supermicro.com.tw

Tel: 886-2-8226-1900

Returning Merchandise for Service

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service will be rendered. You can obtain service by calling your vendor for a Returned Merchandise Authorization (RMA) number. When returning to the manufacturer, the RMA number should be prominently displayed on the outside of the shipping carton, and mailed prepaid or hand-carried. Shipping and handling charges will be applied for all orders that must be mailed when service is complete.

For faster service, RMA authorizations may be requested online (<http://www.supermicro.com/support/rma/>).

Whenever possible, repack the backplane in the original Supermicro box, using the original packaging materials. If these are no longer available, be sure to pack the backplane in an anti-static bag and inside the box. Make sure that there is enough packaging material surrounding the backplane so that it does not become damaged during shipping.

This warranty only covers normal consumer use and does not cover damages incurred in shipping or from failure due to the alteration, misuse, abuse or improper maintenance of products.

During the warranty period, contact your distributor first for any product problems.

Chapter 1

Safety Guidelines

To avoid personal injury and property damage, carefully follow all the safety steps listed below when accessing your system or handling the components.

1-1 ESD Safety Guidelines

Electrostatic Discharge (ESD) can damage electronic components. To prevent damage to your system, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing a component from the antistatic bag.
- Handle the backplane by its edges only; do not touch its components, peripheral chips, memory modules, or gold contacts.
- When handling chips or modules, avoid touching their pins.
- Put the card and peripherals back into their antistatic bags when not in use.

1-2 General Safety Guidelines

- Always disconnect power cables before installing or removing any components from the computer, including the backplane.
- Disconnect the power cable before installing or removing any cables from the backplane.
- Make sure that the backplane is securely and properly installed on the motherboard to prevent damage to the system due to power shortage.

1-3 An Important Note to Users

- All images and layouts shown in this user's guide are based upon the latest PCB revision available at the time of publishing. The card you have received may or may not look exactly the same as the graphics shown in this manual.

1-4 Introduction to the Backplanes

The BPN-NVMe3-136NB-L/NB-R/PL/PL-J backplane has been designed to utilize the most up-to-date technology available, providing your system with reliable, high-quality performance.

This manual reflects BPN-NVMe3-136NB-L/NB-R/PL/PL-J Revision 1.00, the most current release available at the time of publication. Always refer to the Supermicro Web site at www.supermicro.com for the latest updates, compatible parts, and supported configurations.

Chapter 2

Connectors and Pin Definitions

2-1 Front Connectors




Figure 2-1. Front View of BPN-NVMe3-136NB-L




Figure 2-2. Front View of BPN-NVMe3-136NB-R




Figure 2-3. Front Connectors of BPN-NVMe-136PL

- | | |
|--------------------------------|-----------------------------------|
| 1. Amphenol Connector C: MCN3. | 4. PCIe Slot 1: MJ1. |
| 2. Amphenol Connector B: MCN2. | 5. PCIe Slot 2: MJ3. |
| 3. Amphenol Connector A: MCN1. | 6. Power Connector: MP1 (12-pin). |




Figure 2-4. Front Connectors of BPN-NVMe3-136PL-J

- | | |
|---|---|
| <p>7. zCD Connectors: J2, J1, J4, and J3.</p> <p>8. PCIe Slots: JPCIE1 and JPCIE2.</p> <p>9. Amphenol Connector B: MCN2.</p> <p>10. Amphenol Connector B: MCN5.</p> <p>11. Amphenol Connector A: MCN1.</p> <p>12. Amphenol Connector C: MCN3.</p> | <p>13. Amphenol Connector A: MCN4.</p> <p>14. Amphenol Connector C: MCN6.</p> <p>15. Power Connectors: MP2 and MP1 (12-pin).</p> <p>16. Power Connectors: PSU2 and PSU1.</p> <p>17. Fan Connectors: FAN1, FAN2, FAN3, FAN4, FAN5, FAN6, FAN7, and FAN8.</p> |
|---|---|

2-2 Front Connector Pin Definitions

#1. - 3. and #9. - 14. Amphenol Connectors

The Amphenol ports are used to connect the Amphenol slim-line cables between BPN-NVMe-136PL and BPN-NVMe-136PL-J. They are designated MCN1, MCN2, and MCN3 for BPN-NVMe-136PL and MCN1, MCN2, MCN3, MCN4, MCN5, and MCN6 for BPN-NVMe-136PL-J. To connect two BPN-NVMe-136PL SSD trays to one BPN-NVMe-136PL-J JBOF/NVMF Controller, MCN1, MCN2, and MCN3 of the first BPN-NVMe-136PL should be linked to MCN1, MCN2, and MCN3 of BPN-NVMe-136PL-J, and MCN1, MCN2, and MCN3 of the second BPN-NVMe-136PL should be linked to MCN4, MCN5, and MCN6 of BPN-NVMe-136PL-J.

#4. - 5. and #8. PCIe Slots

The PCIe slots are designated MJ1 and MJ3 for BPN-NVMe-136PL, and JPCIE1 and JPCIE2 for BPN-NVMe-136PL-J. The slots of the BPN-NVMe-136PL are where the NVMe daughter cards are installed, with BPN-NVMe3-136NB-L connecting to MJ1 and BPN-NVMe3-136NB-R connecting to MJ3. JPCIE1 and JPCIE2 can each support an NVMe over Fabrics card.

#6. and #15. - 16. Backplane Main Power Connectors

The power connectors, designated MP1 for BPN-NVMe-136PL and MP1, MP2, PSU1, and PSU2 for BPN-NVMe-136PL-J, provide power to the backplanes. MP1 of BPN-NVMe-136PL connects to MP1 or MP2 of BPN-NVMe-136PL-J. See the table on the right for pin definitions for the 12-pin connectors.

Backplane Main Power 12-Pin Connector	
Pin#	Definition
1 - 6	Ground
7 - 12	+12VDC

#7. zCD Connectors

The zCD connectors, designated J1, J2, J3, and J4, connect to external hosts through zCD cables.

#17. Fan Connectors

These connectors, designated FAN1, FAN2, FAN3, FAN4, FAN5, FAN6, FAN7, and FAN8, provide power to the cooling fans.

2-3 Front Jumper Locations and Pin Definitions





Figure 2-5. Front Jumper of BPN-NVMe-136PL-J

Explanation of Jumpers

To modify the operation of the backplane, jumpers can be used to choose between optional settings. Jumpers create shorts between two pins to change the function of the connector. Pin 1 is identified with a square solder pad on the printed circuit board.

Note: On two pin jumpers, "Closed" means the jumper is on and "Open" means the jumper is off the pins.



Jumper Settings		
Jumper	Jumper Settings	Notes
JPB1	1-2: BMC enabled 2-3: BMC disabled	BMC enabled is the default setting.

2-4 Rear Connectors and LED Indicators




Figure 2-6. Rear Connectors & LED Indicators of BPN-NVMe3-136NB-L

NVMe Connectors and LED Indicators

Rear Connector	Drive Number	Failure LED
NVMe#0	NVMe HDD #0	D14
NVMe#1	NVMe HDD #1	D15
NVMe#2	NVMe HDD #2	D16
NVMe#3	NVMe HDD #3	D17
NVMe#4	NVMe HDD #4	D18
NVMe#5	NVMe HDD #5	D19
NVMe#6	NVMe HDD #6	D20
NVMe#7	NVMe HDD #7	D21

Other Rear LEDs

LED	State	Specification
LED31	Blue	Activity LED: A drive is active.
LED32	Red	Drives status LED
LED33	On	Power LED: Backplane has power.
LED34	On	Unit ID LED: Backplane is selected.




Figure 2-7. Rear Connectors & LED Indicators of BPN-NVMe3-136NB-R

NVMe Connectors and LED Indicators		
Rear Connector	Drive Number	Failure LED
NVMe#8	NVMe HDD #0	D14
NVMe#9	NVMe HDD #1	D15
NVMe#10	NVMe HDD #2	D16
NVMe#11	NVMe HDD #3	D17
NVMe#12	NVMe HDD #4	D18
NVMe#13	NVMe HDD #5	D19
NVMe#14	NVMe HDD #6	D20
NVMe#15	NVMe HDD #7	D21

Other Rear LEDs		
LED	State	Specification
LED31	Blue	Activity LED: A drive is active.
LED32	Red	Drives status LED
LED33	On	Alert LED
LED34	On	LAN LED: Backplane is receiving a signal.




Figure 2-8. Rear View of BPN-NVMe-136PL




Figure 2-9. Rear View of BPN-NVMe-136PL-J

Disclaimer (cont.)

The products sold by Supermicro are not intended for and will not be used in life support systems, medical equipment, nuclear facilities or systems, aircraft, aircraft devices, aircraft/emergency communication devices, or other critical systems whose failure to perform would be reasonably expected to result in significant injury or loss of life or catastrophic property damage. Accordingly, Supermicro disclaims any and all liability, and should buyer use or sell such products for use in such ultra-hazardous applications, it does so entirely at its own risk. Furthermore, buyer agrees to fully indemnify, defend, and hold Supermicro harmless for and against any and all claims, demands, actions, litigation, and proceedings of any kind arising out of or related to such ultra-hazardous use or sale.